

Barrel Cleaning

(1) Patch with Tactical Advantage Accelerator, one pass

(2) IOSSO Nylon Brush with Tactical Advantage Patchout. 10 strokes. Don't let the brush go further than the end of the barrel.

(3) Saturate Brush with Accelerator. 10 strokes. Wait 10 - 15 minutes then step 4.

(4) Patch with Patchout. One pass. Let this sit overnight if there's time.

(5) Dry patch. 2-3 times.

(6) 1-2 size larger nylon brush into the the chamber. Rotate 30 times.

(7) Run one more dry patch through the bore.

(8) Run a patch with Lockeaze through the cleaned barrel to coat the throat area and then back and forth until the patch comes out of the end of the barrel.

(9) .45 Caliber brush with a patch over it. Run it into the chamber to remove any residual cleaner. 2 times

(10) Lube the bolt locking lugs.